

HOW TO PAIR A REMOTE TO ANOTHER ALARM

With the remote that came with the alarm:

1. Press and hold the doorbell button for about 7 seconds (will firstly hear *beep-bawp*, then a few seconds later a final *beep*)

2. With the 2nd Remote pointed at the 1st Alarm, press unlock on the 2nd Remote to pair it with the 1st Alarm. A red light should appear on the alarm and a *beep* should sound to let you know the 2nd Remote has connected with the alarm.


3. Now both remotes are working with the 1st Alarm.

4. To then pair the 1st remote to the 2nd Alarm, start with the remote that came with the 2nd Alarm and:

- Press and hold the doorbell button for about 7 seconds (will firstly hear *beep-bawp* then a final *beep*)

5. With the 1st Remote pointed at the 2nd Alarm, press unlock to pair it with the 2nd Alarm.

6. Now both remotes should be working for every alarm, this can be done with multiple alarms for one remote.



^ DOORBELL BUTTON ^



*A red light will appear when remote is being used with an alarm.